



# HERON INSTRUMENTS INC.

## dipper-See ADVENTURER

### Vertical Downhole Inspection Camera

Length options: 75m/250ft | Warranty: 2 years, probe 1 year

The **dipper-See ADVENTURER** is a **Vertical Downhole Inspection Camera** designed to be easily transported to remote monitoring sites. The **dipper-See ADVENTURER** is an ideal tool for monitoring the well's overall functionality or condition and checking for cracked well casings. Hydrologists and those performing well inspections love the underwater camera for its ease of use and compact size.

#### With its easy 4 step setup, you will be up and running in NO TIME.

1. Open the case and remove the **dipper-See ADVENTURER** reel
2. Hang the reel from the well casing using the well hanger
3. Connect the bridge cable to reel handle, and the other end to port in the case
4. Plug in the battery

#### Features and Advantages:

- **Display** - 26cm (10.1") monitor built into case
- **Battery w/Charger** - Removeable rechargeable **lithium ion**, up to 5 hours (3200mAh) per battery
- **Camera Probe** - 25mm (1") diameter, 316 grade fully pressure rated, field replaceable, 550TVL, w/ 7 ultra-bright LEDs
- **Hanger** - built-in to support the reel at the top of well casing
- **Cable** - Polyurethane
- **Carry Case w/Strap** - Tough **Lightweight NK-7 Polypropylene** to protect your investment from the elements and for easy transport



[www.heroninstruments.com](http://www.heroninstruments.com)



# dipper-See ADVENTURER Features

## All-In-One Design

The **dipper-See ADVENTURER** comes with everything you need to perform a quick and hassle-free well inspection. Ideal for shallow wells, the **ADVENTURER** helps users obtain a **real-time** view of what is happening in the well or borehole. Including compartments for the battery charger and cord, bridge cable, camera probe and reel, the **dipper-See ADVENTURER** efficiently uses the space provided to give all of the accessories a place to be protected within the case.



## Lightweight Durable Carry Case

The **dipper-See ADVENTURER** comes in a practical, lightweight and durable polypropylene, strapped carry case. The case measures **24cm(9.5")** tall, **33cm(13")** wide and **43cm(17")** long, making it easy to sling over your shoulder with the included carry strap, or could be put in the back of a truck on the way to a job-site, while not taking up much space. Weighing only **17lbs(7.6kg)** the **dipper-See ADVENTURER** can easily be brought to any remote monitoring site.

## Built-In Monitor


The **dipper-See ADVENTURER** features a large **26cm(10.1")** display screen built directly into the case lid, that is powered by a rechargeable lithium ion battery providing you up to **5 hours of battery** life on a single charge. Simply attach the battery to the port beside the screen, and you are up and running. There is no need for difficult and time consuming set-ups.



**HERON INSTRUMENTS INC.**

447 Moxley Rd. | Dundas, ON Canada L9H 5E2 | 905-628-4999 | info@heroninstruments.com

Please visit our website [www.heroninstruments.com](http://www.heroninstruments.com) for more information on the complete Heron line.

 Made in Canada