



HERON
INSTRUMENTS INC.

dipper-Tough

Static & drawDown Levels

Lengths Options: 30m/100ft to 300m/1000ft

Warranty: 5 Years, Probe N/A

The **dipper-Tough** is a high quality, robust premium water level meter used for measuring static and falling head levels in landfills, remediation sites, and other harsh environments. The drawDown feature on the **dipper-Tough** makes this unit ideal to use during pump and treat testing when contaminants are found in the groundwater.

One of the major drawbacks of monitoring in these conditions is the need to constantly replace the equipment. The harsh chemicals and other pollutants found in these types of environments makes short work of any instrumentation used.

The **dipper-Tough** boasts a Kynar jacketed, high tensile, steel core tape which is extremely resistant to harsh environments. This tape is embedded directly into the 5/8" probe to allow for longer life and increased resistance to chemical attack.

If you are facing a monitoring project in a potentially harsh or toxic environment the **dipper-Tough** is the obvious choice for accurate results.

Features included with the dipper-Tough:

- **Electronic Module (IP65)** – mode change for static and drawDown levels, removable for easy cleaning and servicing
- **Probe (IP68)** – fully pressure/depth rated
- **Tape** – high tensile steel, jacketed with Kynar, high break strength, stretch resistant and lifelong legibility
- **Padded Carry Case** – to protect your precision water level meter from the elements
- **Tape Guide** – to protect the tape from sharp edges
- **Hanger** – to support the meter at the well head
- **Vinyl Holding Grip** – molded to the frame, **ergonomic easy grip**
- **Winding Handle** – custom made for **easy rewinding** with gloved hands



HERON INSTRUMENTS INC.

447 Moxley Rd. | Dundas, ON Canada L9H 5E2 | 1-800-331-2032 | info@heroninstruments.com
Please visit our website for more information on the complete Heron line. 🇨🇦 Made in Canada

www.heroninstruments.com