

dipper-Tag tag line

Length options: 100ft/30m to 1000ft/300m

Warranty: 3 years

The economical dipper-Tag is a multi-purpose unit designed for use when installing or monitoring wells. The 316 grade s/s plopper that comes with the dipper-Tag can be used for measuring to the bottom of a well, or the depth to the top of a bentonite layer or backfill sand. The spring release clip allows the user to exchange the plopper to other available accessories such as one of our dipper-Lag to measure water levels and temperature for **short term** analysis. The dipper-Tag can also be used with third party accessories (i.e. bailers for water sampling).

Features included with the dipper-Tag:

- Spring Release Clip forged stainless and chrome plated
- Plopper 316 grade stainless steel, 680 grams
- Tape polyethylene, reinforced with Kevlar markings in metric (mm) or engineering scale (1/100')
- Carry Bag to protect your water level meter from the elements
- Tape Guide and Hanger to support the meter at the well head and to protect the tape from sharp edges on the well casing
- Vinyl Holding Grip molded to the frame, ergonomic easy grip
- Winding Handle custom made for easy rewinding with gloved hands



HERON INSTRUMENTS INC.

447 Moxley Rd. | Dundas, ON Canada L9H 5E2 | 1-800-331-2032 | info@heroninstruments.com Please visit our website for more information on the complete Heron line.