



**HERON**  
INSTRUMENTS INC.

## water tape Water Level Meter

with **drawDown** Mode

Length options: 100ft/30m to 1000ft/300m

Warranty: 5 years, probe 1 year

The economical **water tape** is used for measuring **static** water levels in wells, boreholes and standpipes. The **water tape** will signal water with a visual (LED) signal and an auditory (beep) allowing the user to measure accurate to 1/100' or to each mm.


### Features included with the water tape:

- **Electronic Module (IP65)** – removable for easy cleaning and servicing
- **Probe (IP68)** – 5/8" fully pressure/depth rated
- **Tape – Polyethylene**, reinforced with **Kevlar** – markings in metric (mm) or engineering scale (1/100')
- **Carry Bag** – to **protect** your water level meter from the elements
- **Tape Guide and Hanger** – to support the meter at the well head and to **protect** the tape from sharp edges on the well casing
- **Vinyl Holding Grip** – molded to the frame, **ergonomic easy grip**
- **Winding Handle** – custom made for **easy rewinding** with gloved hands



**HERON INSTRUMENTS INC.**

447 Moxley Rd. | Dundas, ON Canada L9H 5E2 | 1-800-331-2032 | info@heroninstruments.com

Please visit our website for more information on the complete Heron line.  Made in Canada

[www.heroninstruments.com](http://www.heroninstruments.com)