

# dipper-See EXAMINER

## **Vertical Downhole Inspection Camera**

**Length Options:** 150m or 500ft **Warranty:** 2 Year

300m or 1000ft

The **Heron dipper-See EXAMINER** is a robust, cost effective, **vertical downhole inspection camera**. Designed with portability in mind, this **self-contained unit** is ideal for viewing in wells, drains, vertical shafts, open bodies of water, boreholes and narrow tubes from 25mm (1") diameter.

The **adjustable positioning arm**, conveniently attached to the frame, offers an ergonomic solution for adjusting the monitor for viewing the **HD display screen** at different angles and lighting conditions. The **built-in hanger** on the frame can support the unit at the top of the well, allowing for hands-free viewing while in the field.

### Features and Accessories Included:

 Camera Probe – 2Gmm (Î Ď") diameter, 316 marine grade, fully pressure rated, field replaceable

- Lens robust, scratch resistant clear sapphire
- 160° wide viewing angle
- LED Lights 7 ultra-bright
- Monitor resolution 600x1024, (7"), full colour, IP65
- Adjustable Positioning Arm a solution for adjusting the monitor for viewing in various angles and lighting conditions
- Batteries (x2) removable, rechargeable lithium ion, up to 5 hours (3200mAh) per battery
- Charger plug type A, AC Input, compact, portable
- DVR- records video and audio feed
- SD Card removable for transferring files to computer
- Microphone 3.5mm jack, for audio voice over
- Centralizer removable, centers and stabilizes camera probe in well
- Retrieval Hook for light weight items
- Monitor Visor for glare free viewing
- Hanger and Tape Guide built-in, to support the unit at the well head and protect the tape from sharp edges
- Tape polyethylene, 4 conductors
- Super Tough, Wheeled Case to transport and protect your investment from the elements



#### HERON INSTRUMENTS INC.

447 Moxley Road, Dundas, ON L9H 5E2 CANADA | 1-800-331-2032 or 905-628-4999 | info@heroninstruments.com Please visit our website www.heroninstruments.com for more information on the complete Heron product line.



# dipper-See EXAMINER Features



### Camera Probe- 160° Wide Viewing:

The detachable camera probe is an **HD** camera that is designed to work in the harshest environments and stand up to the most rigorous use. It is precision machined out of nonferrous **316 marine grade** stainless steel with a **sapphire lens** that is machined in the C - axis for superior strength and clarity. The link connection is designed so that you can quickly remove the camera probe for field replacement and for future camera upgrades.



### **Display Monitor:**

The adjustable positioning arm, attached to the frame, offers an ergonomic solution for adjusting the **dipper-See EXAMINER** display monitor for viewing at different angles and lighting conditions. For ease of use, the monitor conveniently houses the Power and **(DVR)** Mode button on the front. The **SD** card inserted into the provided **DVR** records video/audio and is removable for transferring the information to an external device.



### **Accessories Included:**

- Wheeled Case Lightweight NK7 Polypropylene
- Batteries 11.1v, Lithium Ion
- Battery Charger Plug type A, AC Input
- DVR HD Recorder
- **SD Card** 32 GB
- Microphone 3.5mm Jack
- Centralizer Delrin
- Retrieval Hook Acetal Resin Arm with S/S Hook
- Monitor Visor Nylon
- Cleaning Cloth/Solution Microfibre/Alconox

#### HERON INSTRUMENTS INC.

447 Moxley Road, Dundas, ON L9H 5E2 CANADA | 1-800-331-2032 or 905-628-4999 | info@heroninstruments.com Please visit our website www.heroninstruments.com for more information on the complete Heron product line.