



# HERON INSTRUMENTS INC.

*For Good Measure*

## Water Tape Water Level Meter

with **Drawdown Mode**

Length options: 100ft/30m to 1000ft/300m

Warranty: 2 years, probe 1 year

The economical **water tape** is used for measuring **static** water levels in wells, boreholes and standpipes. The **water tape** will signal water with a visual (LED) signal and an auditory (beep) allowing the user to measure accurate to 1/100' or to each mm. With a touch of a button the unit changes from static to Drawdown mode; a dual function unit at an affordable price.

### Features included with the water tape:

- **Electronic Module (IP65)** – removable for easy cleaning and servicing, now with an adjustable volume control
- **Probe (IP68)** – 5/8" fully pressure/depth rated
- **Tape – Polyethylene**, reinforced with **Kevlar** – markings in metric (mm) or engineering scale (1/100')
- **Padded Carry Case** – to protect your precision water level meter from the elements
- **Tape Guide And Hanger** – to support the meter at the well head and to protect the tape from sharp edges on the well casing
- **PFAS FREE** - Manufactured with wetted material not known to contain PFAS



[www.heroninstruments.com](http://www.heroninstruments.com)

A-825-1902-001-Rev 0